

Operators Manual

FireWire PCI Board

For Macintosh and PC

About this manual

The information in this manual is subject to change without notice. We welcome your comments on any area of Orange Micro products or services. Please send your comments to:

Product Manager
Orange Micro, Inc.
1400 N. Lakeview Ave.
Anaheim, California 92807
marketing@orangemicro.com

Orange Micro may use or distribute any of the information you supply in any way it deems appropriate without incurring any obligations whatsoever.

Warning

This manual and the software described herein are protected by United States Copyright law (Title 17 United States Code). Unauthorized reproduction and/or sales may result in imprisonment for up to one year and fines of up to \$10,000 (17 USC 506). Copyright violators may also be subject to civil liability.

Copyright Information

OrangeLink is a trademark of Orange Micro, Inc. iLink is a trademark of Sony Corporation. Apple, Macintosh, FireWire and Final Cut Pro are trademarks and registered trademarks of Apple Computer, Inc. All brand names are registered trademarks of their respective companies.

Table of Contents

About this manual	2
Table of Contents	3
Package Contents	
Software Included	
System Requirements	
Chapter 1	
Chapter 2 How to install an OrangeLink in your Macintosh Step 1 – Installing your OrangeLink hardware Step 2 – Installing OrangeLink Drivers in the Mac OS Installing FireWire Drivers Step 3 – Installing BTV Pro on your Macintosh	6 6 6
Chapter 3	9
Step 1 – Installing OrangeLink Drivers in Windows Step 2 – Installing your OrangeLink hardware Step 3 – Finalizing OrangeLink hardware settings. Step 4 – Installing Ulead VideoStudio DV SE on your PC. Guidelines for Connecting FireWire Devices	10 10
Appendix A	
Appendix B Using BTV Pro on the Macintosh BTV Pro – QuickStart Additional FireWire Workflow Recommendations and Known Issues:	13 13
Appendix CUsing Ulead VideoStudio on WindowsUlead VideoStudio – QuickStart	16 16
Appendix D Macintosh Troubleshooting PC Troubleshooting	18
Appendix ESpecifications	22
Appendix F	23 23
Indov	26

Package Contents

The OrangeLink FireWire PCI Board package contains the following items:

- FireWire PCI Board
- Manual and Software CD-ROM
- One 6 foot (1.82 meter) 4-pin to 6-pin FireWire cable to connect the OrangeLink to a digital camcorder or other FireWire/IEEE 1394 devices that do not require power from the FireWire bus.
- Quickstart card



Software Included

- Apple QuickTime for Macintosh
- BTV Pro for the Macintosh
- Apple QuickTime for Windows
- Ulead VideoStudio for Windows

System Requirements

Hardware

- Any desktop computer with at least one available 7" or 12" PCI slot
- 64 MB System RAM
- 200 MB free hard drive space
- CD-ROM drive (for software installation)

Operating System

- Windows 98 SE, Me, 2000 or XP come with all drivers necessary to support OrangeLink PCI Board.
- **Mac OS X:** Mac OS 10.1 or newer is required to work properly with the OrangeLink PCI Board. Mac OS 10.1 comes with all drivers necessary to support OrangeLink PCI Board.
- **Mac OS 8.6:** The OrangeLink PCI Board will operate as a fully compliant 1394 OHCI host controller under Mac OS 8.6 after installing Apple FireWire Software v2.3.3
- Mac OS 9.0.x: The OrangeLink PCI Board will operate as a fully compliant 1394 OHCI host controller under Mac OS 9.0.x after installing Apple FireWire Software v2.5 or newer
- Mac OS 9.x: Mac OS 9.1 or newer pre-install all drivers necessary to the support OrangeLink PCI Board.

Power Consumption

 Depending upon the number of devices connected, the OrangeLink PCI Board can consume up to 9 watts of power from the internal power supply

Minimum System Requirements for DV editing (Mac)

- Power Macintosh G3 233 MHz or faster
- Hard drive with sustained write speed of 7.5 MB/s
- Total System RAM of 80MB or more
- Mac OS 9.04 or later
- QuickTime 4.1.2 or later
- Apple FireWire 2.4 or later

Minimum System Requirements for DV editing (PC)

- Intel Pentium III 500Mhz or faster
- Dedicated large capacity 7200 RPM UDMA 66 IDE or SCSI hard disk or disk array
- 128MB or more of system RAM
- Microsoft DirectX compatible video display adapter
- Sound card capable of 16-bit stereo or higher

Chapter 1

Introduction

What is OrangeLink?

The OrangeLink FireWire® host adapters add FireWire support to PCI or CardBus-based Mac's or PC's. It is ideal for older Power Macintosh desktop computers or PowerBook G3 Series as well as PCs that need the advanced technology offered by FireWire® (also known as IEEE-1394 or iLink).

What is FireWire?

FireWire supports the IEEE-1394 High Performance Serial Bus standard. FireWire high-speed serial I/O technology is particularly great for use with multimedia peripherals such as digital video (DV) camcorders and tape decks. The OrangeLink supports other FireWire peripherals such as disk drives, ultra high-resolution scanners, printers and digital still cameras.

OrangeLink Features

The OrangeLink products function at the maximum IEEE-1394 rated speed of 400 megabits/second (50 megabytes/sec). The OrangeLink allows up to 63 devices to be connected in a chain through its standard 6 pin ports. The OrangeLink can be used with third party video editing software to capture, edit and export full size, full motion DV video at 720 by 480 pixels at 30 frames per second.

The Benefits of OrangeLink FireWire

The major benefit for OrangeLink FireWire technology is its ease of use. Imagine automatic device configuration, no device IDs or terminators, simple to use cables, and of course, "hot plug" connectivity. Consider a FireWire disk drive for example. You can disconnect it from one computer and connect it to another; no need to power down or restart. You can move whole databases around your workgroup "live"! Or, when the office day is done, pop it into your shirt pocket and hot plug it to your home computer.

The fastest growing use for FireWire consists of digital video (DV) camcorders. The digital format of these devices provides precise audio and video capabilities in an original digital format that is more directly compatible with a computer than the current analog video cameras. This means that the OrangeLink is ideal for computer based home video editing as well as for more professional applications, e.g. Apple Final Cut Pro™.

Chapter 2

How to install an OrangeLink in your Macintosh

In order to ensure proper operation of your OrangeLink product, please follow the instructions below in the order they appear. These instructions document the installation process for the Orange Micro OrangeLink FireWire PCI board inside PCI-based Power Macintosh systems.

Step 1 - Installing your OrangeLink hardware



NOTES:

Refer to your computer's manual for instructions on how to open your computer and install a PCI card.

The OrangeLink PCI board gets the power it supplies to the FireWire bus from the PCI slot.*

IMPORTANT:

Before Handling the PCI board or touching anything in the computer, ground yourself by touching the power supply for a couple of seconds. Failure to do this may damage the board and/or your computer.

- With your computer off, open your computer case.
- Locate an open PCI slot. If there is a faceplate covering the opening to the back panel, remove it.
- Locate the OrangeLink PCI board and insert it into the free slot. Once inserted, screw the board in securely.
- Connect your internal devices as needed.
- Close computer.

Step 2 - Installing OrangeLink Drivers in the Mac OS

- Insert the OrangeLink FireWire Manual and Software CD. The window pictured on the right should pop up on your Macintosh desktop.
- Double-click on the OrangeLink Installer icon.
- Once the OrangeLink Installer has opened, click "Install." The OrangeLink Installer copies all necessary Orange Micro drivers to the Macintosh Extensions folder. Additional utilities and shortcuts to important Apple software download web sites are copied to a folder named "Orange Micro Updates" on your Macintosh startup drive.
- Click on "Quit" after the OrangeLink Installer has successfully completed the install.



Figure 1. The Installation Window



Installing FireWire Drivers

Once you have finished installing the OrangeLink software, you need to download the most current release of FireWire support from Apple Computer. To download FireWire support, follow these instructions:

NOTE: Mac OS 9.1, 9.2.x and Mac OS X come with FireWire support preinstalled and it is not necessary to download and install FireWire drivers. Mac OS 9.0.x users should download Apple FireWire v2.5 or newer. Mac OS 8.6 users should download Apple FireWire v2.3.3.

- Connect to the Internet in the manner recommended by your Internet Service Provider. A connection to the Internet is vital to the installation of your OrangeLink board, because Apple requires that FireWire support be downloaded directly from its web site (www.apple.com/support).
- Locate the "Download Apple FireWire" AppleScript. This script can be found in the "Orange Micro Updates" folder that was created on your Macintosh startup drive by the OrangeLink Installer.
- Double-click "Download Apple FireWire." If you are connected to the Internet, click "Continue" to connect to Apple's FireWire download section on their web site. If you are not connected to the Internet, you may select "Later" to download Apple FireWire support at a later time.
- Once you have selected "Continue" your web browser will automatically start and download Apple's FireWire Support from their web site.
- Follow the instructions on Apple's web site to download the FireWire Support installer to your Macintosh hard drive.
- Run the Apple FireWire Support installer, following all on-screen instructions. When FireWire support has been installed, you will be prompted to restart your Macintosh. Click "Restart."



Congratulations! You have set up your FireWire support on your Macintosh.

NOTE: A file called FireWire Support may be in a folder titled FireWire in the Apple Extras folder on your Macintosh. Do not move this older extension to your Extensions folder; it may interfere with the operation of the new Apple FireWire software.

Step 3 – Installing BTV Pro on your Macintosh

BTV Pro is an application for the Macintosh that allows you to view, capture and edit video, create stop-motion animations, and also has advanced capture features such as frame averaging, time lapse and motion detection.

IMPORTANT: INSTALL THE FOLLOWING SOFTWARE IN THE ORDER LISTED!

Install QuickTime™

To install QuickTime, double-click on the "QuickTime Installer" icon located in the "Manual and Software" CD-ROM. Inside the QuickTime installer choose the "Full" option as your installation type. Make sure you are not working with a beta version of QuickTime!

Install BTV Pro on your Macintosh

Double-click the "Install BTV Pro" icon on the "Manual and Software" CD-ROM. A folder named "BTV Pro 5.1 folder" will be created on your Macintosh hard drive.

Adobe Acrobat® Reader

You can install the Adobe Acrobat Reader software by double-clicking the "Reader Installer" icon on the "Manual and Software" CD-ROM in the Acrobat Reader folder. Much of the documentation included on this CD-ROM is provided in the Adobe Acrobat portable document format (PDF). You may view and print these PDF files with the Adobe Acrobat Reader.

The "BTV Pro 5 manual.pdf" is in Acrobat PDF format. It is installed in the "BTV Pro folder" on your Macintosh hard drive

Chapter 3

How to install an OrangeLink in your PC

In order to ensure proper operation of your OrangeLink product, please follow the instructions below in the order they appear. These instructions document the installation process for all Orange Micro OrangeLink products inside your Windows PC.

Step 1 – Installing OrangeLink Drivers in Windows

Orange Micro OrangeLink FireWire PCI board may be used on any Intel Pentium or compatible system running Microsoft Windows 98 Second Edition, Windows Me, Windows 2000 or Windows XP. OrangeLink products are not compatible with any previous versions of Windows.

NOTE: Microsoft refers to FireWire as IEEE-1394; the two names are synonymous.

- Insert the OrangeLink Installer CD. Once inserted, the OrangeLink Installer will automatically start and display the menu to the right.
- The OrangeLink Installer will automatically start.
- Click on "Install OrangeLink Drivers"



- Follow the onscreen instructions.
- When prompted, restart your computer.

Step 2 - Installing your OrangeLink hardware



NOTES:

Refer to your computer's manual for instructions on how to open your computer case and install a PCI card. The OrangeLink PCI board gets the power it supplies to the FireWire bus from the PCI slot.

IMPORTANT:

Before Handling the PCI board or touching anything in the computer ground yourself by touching the power supply for a couple of seconds. Failure to do this may damage the board and/or your computer.

- With your computer off, open your computer case.
- Locate an open PCI slot. If there is a faceplate covering the opening to the back panel, remove it.

- Locate the OrangeLink PCI board and insert it into the free slot. Once inserted, screw the board in securely.
- Connect your internal devices as needed.
- Close computer.
- Turn the computer power on.


Step 3 – Finalizing OrangeLink hardware settings

Check your Windows System/Device Manager to confirm proper installation of FireWire drivers:

1394 Bus Controller

-Orange Micro OrangeLink OHCI IEEE 1394 Host Controller





Windows 2000

Windows 98 Second Edition

Your hardware is ready for use, and you may continue on to Step 4 - Installing Ulead VideoStudio on your PC.

Step 4 – Installing Ulead VideoStudio DV SE on your PC

To install Ulead Video Studio, insert the OrangeLink "Manual and Software" CD-ROM into your CD-ROM drive. When the OrangeLink Installer loads the OrangeLink Setup Menu, select "Install Ulead VideoStudio."

NOTES:

Be sure to have your camcorder attached to a FireWire port and previewing video during the Ulead Video Studio installation. VideoStudio will detect the camcorder and install appropriate drivers.

The Ulead VideoStudio software installation instructions are on the OrangeLink "Manual and Software" CD in the Adobe Acrobat portable document format (PDF). Click on the box next to "Browse This CD" and double click on vstudio.pdf. If Adobe Acrobat Reader is installed on your system, Acrobat Reader should automatically open vstudio.pdf.

Once the file is open, scroll down to the contents page (3). There you will see 7: Installation. Click on 7 and you will see the installation instructions for VideoStudio DV SE. Follow these instructions to install the Ulead software.

Chapter 4

Guidelines for Connecting FireWire Devices

FireWire devices can be connected in any combination of branching and chaining, as long as no loops are formed. A FireWire bus can support up to 16 consecutive cable hops of 4.5 meters (14.76 feet) each. There are no SCSI-style ID numbers to set and no termination requirements.

The OrangeLink FireWire PCI products are designed to keep the FireWire network operating even if the computer is shut down. Loss of power to the computer will not affect the operation of a FireWire board as long as it can draw power from other devices on the FireWire bus. The OrangeLink FireWire PCI board draws its power from the PCI bus.

To connect a DV camera, plug the 6-pin connector on the supplied FireWire cable to the OrangeLink PCI FireWire Board and the 4-pin connector to the camera's IEEE 1394 (DV IN/OUT, iLink) port. Both connectors snap into place when properly engaged. If you wish to connect two computers together (or if your device has a 6-pin FireWire port), you can obtain 6-pin to 6-pin cables through an AV equipment retailer, electronics store or directly from Orange Micro.

The OrangeLink FireWire PCI board has three FireWire ports, as shown in the following illustration.



- Do not connect more than 63 (including the computers) devices at one time
- Do not connect devices in such a way that any two devices have more than 16 cables directly connected between them.
- Unused FireWire connections should be left empty. There are no terminators for FireWire connections.
- Connect devices that require power from FireWire directly to the computer.
- Do not unplug a FireWire device while it is being used. For example, do not unplug a FireWire disk while copying files
 onto it.
- If you have problems with digital video transfers make certain that no other FireWire devices are being used at the same time.

Appendix A Optional Hardware

The following optional OrangeLink hardware accessories are available from Orange Micro:

FireWire cable Part# 70CAB13942

4.5 meter (15 feet) 6-pin to 6-pin

FireWire cable Part# 70CAB13943

4.5 meter (15 feet) 6-pin to 4-pin

USB 2.0 Certified cable Part# 70CAB90033

4.5 meter (15 feet)

FireWire Repeater Part# 70HTL00020

Allows an additional 4.5 meter extension for FireWire devices. Includes a 4.5 meter (15 foot) 6-pin to 6-pin cable.

FireWire Hub Part# 70HTL00030

Connects up to 8 devices. Also provides an additional 4.5 meter extension, and an enhanced 12 volts of power for FireWire

peripherals.

USB 2.0 Hub Part# 70USB90030

Connects up to 4 devices. Also provides an additional 4.5 meter extension.

FireWire PCI Board Part# 70HTL13943

Add 3 FireWire ports to your PCI based Mac or PC.

USB 2.0 Hi-Speed PCI Board Part# 70USB90010

Add 5 USB 2.0 Hi-Speed ports to your PCI based Mac or PC.

FireWire for Notebooks Part# 70HTL00040

Add 2 FireWire ports to your Mac or PC Notebook.

OrangeUSB, USB 2.0 for Notebooks Part# 70USB90020

Add 4 USB 2.0 Hi-Speed ports to your Mac or PC Notebook.

USB 2.0 / FireWire for Notebooks Part# 70USB90040

Add 2 FireWire and 2 USB 2.0 ports to your PC Notebook.

USB 2.0 FireWire PCI Board Part# 70HTL00110

Add 2 FireWire and 3 USB 2.0 Hi-Speed ports to your PCI based Mac or PC.

FireWire/SCSI U2W PCI Board Part# 70HTL00080

Add FireWire and SCSI U2W support to your PCI based Mac or PC

FireWire/Ethernet PCI Board Part# 70HTL00090
Add 2 FireWire ports and Ethernet support to your PCI based PC Only.

WebCamDV Part# 70WDV00001

DV Camcorder to Web Cam Converter software

Optional OrangeLink FireWire for Notebooks Power Supply

Avoid buying a FireWire Hub for the purpose of supplying power to the FireWire Bus. Available from:

http://www.1394firestation.com/

Information about the IEEE 1394 Trade Association and many other FireWire products can be found at these addresses:

http://www.1394ta.org http://www.1394showcase.com http://www.apple.com/firewire/firewireproducts.html

Additional information about USB products can be found at the following web address:

http://www.usb.org/

Appendix B

Using BTV Pro on the Macintosh

BTV Pro - QuickStart

What Extensions and Control Panels are needed for working with DV in BTV Pro?

When working with DV and BTV Pro, it is recommended that you set up a custom extension set. The following sample extension set includes the required BTV Pro and System files. Extension versions and their existence in your system may vary depending on which OS you use and what you have installed. Pay special attention to the <u>underlined</u> extensions. Make sure they are enabled before moving on to the next step.

ATI 3D Accelerator 4.9.7 (Note 1)

ATI Driver Update 1.5.3 (Note 1)

ATI Graphics Accelerator 4.9.4 (Note 1)

ATI MPP Manager 1.1.2f1 (Note 1)

ATI Rage 128 3D Accelerator 5.8.1 (Note 1)

ATI Resource Manager 2.4.8 (Note 1)

ATI Video Accelerator 4.2.2 (Note 1)

ATI Video Accelerator Update 1.0.2 (Note 1)

FireWire Enabler (2.4 or newer)

FireWire OrangeLink PC Card 1.1.4 (PC Card Only)

FireWire Support (2.4 or newer)

Open TransportLib 2.0.3

OpenTptInternetLib 2.0.3

OpenTptAppleTalkLib 2.0.3

Open Transport Library 2.0.3

Open Tpt Internet Library 2.0.3

Open Tpt AppleTalk Library 2.0.3

QuickTime Extensions folder

QuickTime Authoring 4.1.1

QuickTime Capture 4.1.2

QuickTime Effects 4.1.1

QuickTime Image 4.1.1

QuickTime Internet Extras 4.1.1

QuickTime Music 4.1.1

QuickTime Player Extras 4.1.1

QuickTime Streaming 4.1.1

QuickTime Streaming Authoring 4.1.1

QuickTime Streaming Extras 4.1.1

QuickTime Web Helper 4.1.2

QuickTime FireWire DV Enabler (2.2 or newer)

QuickTime FireWire DV Support (2.2 or newer)

QuickTime™ 4.1.2

QuickTime™ MPEG Extension 1.1.2

QuickTime™ Musical Instruments 4.1.1

QuickTime™ PowerPlug 4.1.2

QuickTime™ VR 2.3

Shared Library Manager PPC 2.0.2

Shared Library Manager 2.0.2

Sound Manager 3.6.5

Note 1- G3 models with an ATI RAGE 128 graphic accelerator card or ATI RAGE Pro graphic accelerator chip.

Note 2- Remove any other DV or FireWire files except those underlined above.

Capturing Video

At this point you should have already installed the OrangeLink software and BTV Pro software. The FireWire drivers will not recognize most camcorders if the camcorder, Macintosh, and BTV Pro software are not started in the right order. Performing the following procedures in order will guickly get you started capturing DV video.

- Be sure that the Macintosh is OFF, the camcorder power is OFF and the FireWire cable is connected securely to the camcorder DV port and the OrangeLink FireWire port.
- Start your Macintosh.


Note: For optimal performance; Set the Monitor Control Panel to "Thousands" of colors. Set the Memory Control Panel to Virtual Memory OFF and Disk Cache to 128k.

- When the Macintosh has completely started, configure the camcorder to Camera mode (some camcorder manufacturers refer to this as Recording mode) and turn ON the power to the camcorder.
- Listen to your Macintosh hard disk. When the camcorder is detected, the FireWire software will load and you will hear a burst of disk access while the FireWire drivers load.
- Set the capture scratch disk and folder: Pull down the Settings "Preferences..." menu. Click on the "Frame Capture" tab. Click on the "Capture destinations..." button to set which hard drive is your capture drive. Drives that are too slow, fragmented or full will not work well.

Note: Set BTV Pro capture scratch disk and folder to an AV/DV rated drive (DV requires a sustained transfer rate of 3.6 MB/second) with ample amounts of free space.

- Pull down the Apple / Control Panels/ AppleTalk menu. Under the Options button select Make AppleTalk Inactive. Capturing DV works best when AppleTalk is inactive.
- Pull down the BTV Pro Windows menu and select "Capture Controls".
 Now, when you wish to capture video click on the "Start Capturing Movie" button. The same button will represent the "Stop Capturing Movie" button.





Output Video to FireWire

To output your edited movie from BTV Pro back to your DV Camera or Deck you will need to perform the following steps.

• Make sure your DV Camcorder is in VTR/VCR mode on standby. BTV Pro will take control of the camera and switch it to record mode as it exports.

Note: DV cameras have two kinds of record buttons (one for VTR/VCR and one for live camera mode).

- Open the movie you wish to export.
- Pull down the BTV Pro Movie menu and select "Output to FireWire".
- Click on the BTV Pro Play button to send your movie to the DV camcorder.
- Once BTV Pro is done exporting video, it will stop the camera and place it back into standby mode. At this point you can go to your camera and playback the exported video.

If your audio plays clipped during a Output to FireWire, you may not have a fast enough hard drive for DV output or you may be running out of disk space. Set BTV Pro capture scratch disk and folder to an AV/DV rated drive (DV requires a sustained transfer rate of 3.6 MB/second) with ample amounts of free space. You will get better performance if your movies are on a separate drive from your Mac System drive. G3's with SCSI drives should be capable of handling DV. Macs with IDE drives may require a faster drive to output to DV. You can check what kind of hard drive you have by using the Apple System Profiler under the Apple Menu. You should use disk-defragmenting utilities like Norton Utilities' Speed Disk to optimize AV/DV rated drives for best performance.

For additional Mac troubleshooting tips refer to Appendix D.

Additional FireWire Workflow Recommendations and Known Issues:

- Editing DV is a CPU and hard drive intensive task. You may need to minimize your extension sets (via the Extensions Manager and optimize your hard drives (using a Mac disk defragmentation utility like Norton Speed Disk) to get the best possible performance out of your computer.
- Do not expect full screen overlay of video to play well on the computer monitor since the CPU is handling it. Use BTV Pro assemble your video, then export it back to your DV camcorder, which is capable of playing the movie back to the TV monitor full screen.
- There is a QuickDraw 3D compatibility problem, which causes ATI overlay problems. You may experience your markers being overdrawn by the clip overlay. To avoid this, you may disable QuickDraw 3D by creating a custom extension set.
- It is recommended that no other operations be attempted while Capturing or Outputting Video to FireWire.
- The current Apple FireWire 2.4 extensions allow for multiple devices, but they share the same FireWire channel for sending/receiving DV data. This might lead to difficulties selecting between multiple devices during. It is recommended that you only work with one device at a time and turn off the other devices when not in use.
- Since DV transfers video and audio across a single stream, it is not recommended to attempt audio- or video-only captures.
- With the current ATI Video Software Update 1.0, you will experience a frame redraw artifact during Play Edit in Trim Mode.

For more detailed information regarding the operation of BTV Pro refer to the BTV Pro OM manual.pdf located in the "BTV Pro OM Folder" on your hard drive.

Appendix C

Using Ulead VideoStudio on Windows

Ulead VideoStudio - QuickStart

Capturing Video

At this point you should have already installed the OrangeLink software and VideoStudio DV SE software. The FireWire drivers will not recognize most camcorders if the camcorder, the PC, and the VideoStudio software are not started in the right order. Performing the following procedures in order will guickly get you started capturing DV video.


- 1. Be sure that the PC is OFF, the camcorder power is OFF and the FireWire cable is connected securely to the camcorder DV port and the OrangeLink FireWire port.
- 2. Start your PC.
- 3. When the PC has completely booted, configure the camcorder to Camera mode (Some camcorder manufacturers refer to this as Recording mode.) and turn ON the power to the camcorder. Listen to your PC hard disk. When the camcorder is detected the FireWire Software will load and you will hear a burst of disk access while the FireWire drivers load. If you are presented with the following "Version Conflict" dialog, click yes.
- Check the Windows System/Device Manager for the following devices:


1394 Bus Controller:

-Orange Micro OrangeLink OHCI IEEE 1394 Host Controller Imaging Device:

-Microsoft DV Camera and VCR

Note: The "Imaging Device" will only appear if Windows detects the camera. If the above devices do not appear as shown, highlight the device that appears under 1394 Bus Controller and click on the Remove button at the bottom of the Device Manager Window. Then insert the "OrangeLink Manual and Software CD" and select the "Install OrangeLink Drivers" option. Restart Windows then compare the above devices to ensure they appear as shown.





- 5. Double-click the Ulead VideoStudio icon on your desktop. Follow the onscreen instructions to begin capturing video. For any help on capturing video with VideoStudio, insert the "OrangeLink Manual and Software CD". It should Auto Start. Click on the box next to "Browse This CD" double click on vstudio.pdf. You are now ready to start capturing video!
- Verify VideoStudio settings. Point and click on the (Settings and Commands icon). The Settings and Commands menu to the right will appear:

Verify the following Settings:

Select Device Control... = MS 1394 Device Control

Change Capture Plug-in... = Ulead DirectShow Capture plug-in



Additional FireWire Workflow Recommendations and Known Issues:

Optimize your System

If you do not optimize your system you may get dropped audio or video frames. This can cause choppy sound or video that does not appear smooth.


Run Disk Defragmenter on your hard disk. With all applications closed, click on the Windows Start menu and select Start / Programs / Accessories / Systems Tools / Disk Defragmenter to start defragmenting.

Enable DMA for IDE hard disks. In the Windows System/Device Manager double click on Disk Drives. Then double click on the icon labeled Generic IDE Disk. Select the Settings tab and click on the DMA box. Close all windows and restart the Windows operating system. Not all hard drives support DMA. If any problems result due to this procedure, restart Windows in safe mode and remove the check on the DMA box.

Interrupt Conflicts

Interrupt sharing conflicts can cause dropped frames; device not found errors and general protection faults (GPF). To resolve these interrupt sharing conflicts, view your system resources by right clicking on My Computer on your Windows desktop and selecting "properties." Double-click on the Computer icon at the top of the System/Device Manager. This will bring up a window listing your device IRQ's.

The OrangeLink PCI FireWire boards work best when occupying an IRQ value of 9, 10, 11, 12, 14, or 15 by itself or with no additional devices (IRQ holder for PCI Steering and other ACPI items refer to resource designations and may be ignored).



To isolate the OrangeLink PCI board on an IRQ by itself, it may be necessary to move the OrangeLink PCI to different PCI slots. While performing this operation, remove all non-essential PCI cards. Once you can capture video properly reinstall non-essential PCI cards in your system.

Note: Some systems are particular about which slots contain active PCI cards. Put the OrangeLink PCI card in the slot closest to the power supply. Try putting SCSI, Ethernet, Sound or VDD cards in slots below the OrangeLink PCI card. If you have enough open slots, leave slots empty between the OrangeLink PCI card and other PCI cards.

For additional troubleshooting tips go to our web site.

http://www.orangemicro.com/fagolwin.html

Appendix D

Macintosh Troubleshooting

Problem – Can I boot from a FireWire hard drive? Suggestion:

Yes. FireWire booting is possible on all Macintosh models that have built-in FireWire ports with the exception of the Power Macintosh G3 (Blue & White) and the Power Mac G4 (PCI Graphics) models. You may need to upgrade your computer firmware before FireWire booting will work. There is no firmware upgrade for a Beige G3 or Apple PowerBooks that do not have built-in FireWire ports.

If you put any of our FireWire cards in one of the new Macs with updated firmware, you can boot to a FireWire drive connected to our FireWire card. As you can see, booting to a FireWire drive is not a function of the FireWire card

Problem – What are the minimum system requirements to use the OrangeLink? Suggestion:

The PCI based boards can be used on any PCI based Macintosh. The devices that can be used are FireWire hard drives, CD-R's, printers, cameras etc.... DV editing has more stringent requirements and may not be possible on some older systems.

Problem – Apple FireWire will not install in my Mac OS 8.6 system. What should I do? Suggestion:

Apple recommends FireWire software version 2.3.3 for systems with Mac OS 8.6 installed. http://download.info.apple.com/Apple_Support_Area/Apple_Software_Updates/

Problem – My OrangeLink appears to be dead Suggestion:

Ensure the OrangeLink is securely inserted into its slot. Go to the Mac System/Extensions Folder and trash all FireWire extensions. Reinstall OrangeLink Software. Refer to Chapter 2.

Problem – I have installed the card and the OrangeLink Software and now my Mac will not boot. Suggestion:

Try moving the card to a different PCI Slot? If you have other PCI cards as well, try switching the order the cards are installed on the board. The Macintosh can be particular about PCI hierarchy. Move the OrangeLink board into the first PCI slot if possible.

Problem – I can capture video, but when I export I get blocky video back to the camera. Suggestion:

If you have a processor upgrade card installed, confirm that the G3 upgrade card has the proper bus speed settings to match your system. If you have a 50 MHz bus on your system and your upgrade card is running at 48.5, the timing difference will cause the kind of problem you currently have. If your system has a 50mhz-bus speed, and your upgrade card has your system running at 345hz, then your card needs adjusting.

Problem – FireWire does not function or I receive an error message when trying to access a device attached to the FireWire card.

Suggestion:

There may be a 3rd party extension conflict with the Apple FireWire extension. The best way to determine this is to use the Mac OS base extensions set. If the problem stops after restarting your system with this set, you have an extension conflict and you will have to track down the offending extension.

Note: If you are trying to access a CD-RW using Toast, the Apple "FireWire Authoring Support" extension can create a conflict. You should disable it in your Extensions Manager and restart your computer.

Problem – After launching BTV Pro OM. I receive the following error message "Could not find an Orange Micro FireWire card or iBOT camera".

Suggestion:

BTV Pro OM is a special version of BTV Pro that only works if it detects an Orange Micro FireWire card or an iBOT camera under Mac OS. If you have one of these products installed in your computer and you still get this error message, remove the Orange Micro product from your computer and reinstall it. Verify that Apple FireWire extensions are installed. If you have an iBOT, verify the FW iBOT Camera extension is in your System Extensions folder.

Also try setting your Extensions Manager to Base 9.x. Enable the FW iBOT Camera extension, if applicable. Restart you Macintosh. This will eliminate the possibility of an extension conflict.

Other recommendations:

- 1. You should optimize your hard drive by defragmenting it. Install all the most current software updates from our website, Apple's website, and Adobe's website.
- 2. Run your system with an extremely bare extension set. Save an extension set specifically for FireWire editing. Your video editing software and camera will be the only things you are using, so you can disable many extensions to speed up the system.
- 3. Disable "OrangeLink PC card enabler if not using PC Card.
- 4. Disable QuickTime VR, and QuickTime Musical Instruments.
- 5. Disable the Desktop picture (Appearance Control Panel).
- Disable all USB extensions, SerialShimLib, and HID Library.
- 7. Disable any extensions from current software programs such as MS OFFICE.
- 8. Disable Printer extensions, and other device extensions not FireWire.
- 9. Remove all old extensions from software and printers no longer being used.
- 10. When running your camera, run it from the AC Adapter. Run no other devices or programs. These steps should greatly reduce or eliminate the problems you are having with video editing.

For additional troubleshooting tips go to our web site. http://www.orangemicro.com/faqolmac.html

PC Troubleshooting

Problem – I run Windows 98 SE and after plugging in my DV camcorder it shows up in the Windows Device Manager under the "Sound, video and game controllers" section instead of under the "Imaging Device" section. Suggestion:

Open then Windows Device Manager, expand the "Sound, video and game controller" section then remove the device driver for your camcorder. After closing the Device Manager, Windows will prompt you to restart. Select "No".

From the Start menu button select Find\Files or Folders. The Find dialog will now appear. Enter "dvcam.*" under the "Named" section and click the "Find Now" button. Windows should find three files which match the aforementioned criteria. Delete all three of these files.

Insert your Windows 98 Second Edition CD into your CD-ROM drive then restart Windows. As Windows restarts, the camcorder will be detected. When prompted point the Hardware Installation Wizard to the Win98 folder on the Windows 98 SE CD to install the appropriate drivers for your camcorder.

Problem – I have installed the OrangeLink drivers and OrangeLink card, but when I turn on my camera, Windows asks me to load the camera driver.

Suggestion:

If your system is asking for camera drivers, then you will need to update your Windows to Windows 98 Second Edition. If you right click on the My Computer icon, and choose properties, your system properties box will open. This box will display the version of windows you currently have. If the date for Windows is 4/10/1998 and does not say Second Edition, you will need to upgrade to Windows 98 SE

Problem – I cannot get disk media to work properly in Windows 98 Second Edition What can I do? Suggestion:

An update to Windows 98 SE is available that corrects problems with mass storage devices. Use the link below to go to the Microsoft web page and download the update.

http://www.microsoft.com/Windows98/downloads/contents/WURecommended/S_WUFeatured/1394/Default.asp

Problem – Are there any recommended updates for DV editing? Suggestion:

Microsoft recommends users of Digital Video equipment install DV Updater for DirectX 8.1 http://www.microsoft.com/directx/

Problem – How to prepare a FireWire disk for use under Windows 98SE or Windows Me? Suggestion:

- 1. Boot up your computer with the FireWire hard drive turned on and connected.
- 2. From the Start\Programs menu select "MS DOS Prompt". The MS DOS Windows will now appear. From command prompt type "fdisk" and hit the enter key.
- 3. When asked to enable Large Disk support press "Y".
- 4. The Microsoft Fixed Disk Utility will open. Choose option 5 "Change current fixed disk drive" then hit the Enter key.
- 5. Now select your FireWire drive from the list. Your main internal hard drive will be Disk 1. If you have only one hard drive in your computer then drive 2 will be your FireWire drive. If you are not sure which drive is your FireWire drive you should contact the manufacture of the drive for further instructions. After selecting your FireWire drive from the list hit the enter key to proceed.
- 6. WARNING: FAILING TO SELECT THE CORRECT DRIVE MAY CAUSE PERMANENT LOSS OF DATA!
- 7. You will now be presented the original menu of 5 items. Select option 1 "Create DOS partition or Logical DOS drive" and hit Enter.
- 8. You will now be presented 3 menu items. Choose number 1 "Create Primary DOS Partition" then hit the Enter key.
- 9. You will now see the question "Do you wish to use the maximum available size for the Primary DOS partition"? Answer ves.
- 10. The partitioning is complete hit the Esc button twice. You will see a message that you must restart your computer. Hit the Esc button once more to exit the fdisk program. From the MS DOS command prompt type "exit" to close the MS DOS Prompt window.
- 11. Disconnect the drive from the FireWire bus, wait about ten seconds, then reconnect the drive. After plugging the drive back in double click the "My Computer" icon to open the My Computer window. You should have a new drive icon for the FireWire drive. Right click on the drive icon for the FireWire drive. From the pop-up menu that appears select "Format". From the format dialog select "Full" under "Format Type, then click the Start. You will see a warning that all files will be destroyed. Click OK to proceed. This process may take several minutes. Once complete, click the Close buttons and you are done.

Problem – How do I prepare my FireWire Disk for use under Windows 2000? Suggestion:

- 1. Plug the FireWire drive into any available FireWire port.
- 2. The system should detect the drive and install a device driver for it. To verify the drive is properly detected right click on the "My Computer" icon. From the popup menu that appears click Properties. The System Properties dialog will appear. Click the Hardware tab then click on the Device Manager button. The Device Manager dialog will appear. Scroll down through the list of devices until you see the Disk Drives section. Expand this section. Under the Disk Drive section your FireWire drive should be listed. For information on how your drive will show up in the Device Manager please contact the manufacturer of your drive.
- 3. After you have verified that your FireWire drive has been detected by Windows 2000 you will need to partition and format the drive before it will be usable. Open the Disk Management utility. To get there: Click on the Start/Settings/Control Panel menu. Double-click on Administrative Tools, and then double-click on the Computer Management icon. In the Storage sub-section, click Disk Management.
- 4. The Write Signature and Upgrade Disk Wizard will start. Click Next to start the Wizard. Select your FireWire drive from the list using the checkbox. Click Next to continue. Click Finish to write the signature to the drive.
- 5. The FireWire drive will be listed without a drive letter, and show as "unallocated".
- 6. To create a partition, right click on the unallocated area of the drive. Then from the popup menu that will appear select Create Partition.
- 7. The Create Partition Wizard will start. Click next to start the Wizard. Choose Primary partition then click next. Enter the amount of disk space to be used and then click next. Assign a drive letter or path, and then click next. Select a file system to use to format the disk, then click next. Verify all settings, and then click Finish to begin formatting the drive. Note: The formatting process could take several hours.
- 8. When the formatting process has finished, your FireWire drive should then be available for use.

Problem – I followed the instructions, loaded the Driver software, but no 1394 Bus controller is listed in the Device Manager.

Suggestion:

Before the Orange Micro OrangeLink 1394 Host Controller will appear in the Device Manager, you must install the OrangeLink card in your computer. After installing the card and re-booting, Windows will prompt you to insert the Windows CD to finish installation. The "Orange Micro OrangeLink OHCI IEEE 1394 Host Controller" will now appear in the Device Manager.

Problem – I installed the software. I installed the card but when I look in my Device Manager there is a yellow exclamation point on "Orange Micro OrangeLink OHCI IEEE 1394 Host Controller." Suggestion:

This explanation point usually means there is a resource conflict between the OrangeLink card and another card in your system.

Shutdown your computer and move the OrangeLink to another open slot.

If you do not have open slots, swap slots with another card in your system.

Restart your computer. Windows will then re-configure itself and re-assign resources. Check your device manager again. If the explanation point is still there then repeat the process until it no longer appears.

Problem – I get choppy sound or video that does not appear smooth. Suggestion:

Check the amount of RAM in your system. The recommended amount is 128MB or higher, preferably 256MB or more. Check your hard drive for available space. Editing DV takes up large amounts of disk space. As your hard drive fills up the slower it performs.

Try to free up space on your hard drive by deleting unneeded programs and files. Optimize your system.

Problem – Windows 98 SE does not detect my camcorder.

Suggestion:

Some camcorders have problems being detected when they are not plugged into their power supply.

For additional troubleshooting tips go to our web site. http://www.orangemicro.com/fagolwin.html

Appendix E

Specifications

Hardware Features

PCI 2.1 Compliant (FireWire PCI Board only)

FireWire Ports

- IEEE-1394 OHCI compliant; 100 (12.5 MB/sec) Mbits/s; 200 Mbit/s (25 MB/sec); 400 Mbit/s (50 MB/sec)
- Connect up to 63 devices, internal or external
- All FireWire ports provide up to 12 V of power
- Supports Plug-and-Play Specification
- Hot Plug
- Complies with Standard for a IEEE-1394 High Performance Serial Bus/ iLink
- Up to 16 consecutive cable hops of 4.5 meters
- Support for digital video in full size, full motion video of 720 by 480 pixels at 30 frames per second
- Isochronous and Asynchronous data transfer
- Function Control Protocol (FCP)
- Connection Management Protocol (CMP)

Connectors

• Three external 6-pin FireWire ports

Appendix F

Warranty Information

LIMITED WARRANTY

Every Orange Micro product is fully tested and checked for quality prior to shipment. It is warranted to be free from defects in materials and workmanship for a period of one (1) year from date of purchase. During this time period, Orange Micro Inc. will, at no charge to the purchaser of record, repair or replace the defective unit returned to the Customer Service Department in accordance with the following instructions:

NOTE: DO NOT return the Orange Micro product to Orange Micro Inc. until you have received a Return Material Authorization (RMA) Number. Customers outside the United States should contact the Orange Micro distributor in that country and request service.

- 1. Phone the Orange Micro Customer Service Department at 714 779-2772. Customer Service hours of operation are between 8AM and 4PM PST. Customer Service lines are closed from 12PM to 1PM PST for lunch. Obtain a Return Material Authorization (RMA) number.
- 2. Provide Orange Micro, Inc. with Model, Serial Number, Proof of Purchase, Return Address, and preferred return shipping method. Enclose a clear description of the problem experienced and any sample printouts showing the problem, if possible.
- Ship in the original carton or securely packed in a cardboard carton with at least two inches of cushioned packing material on all sides. Mark the package "FRAGILE" and ship via UPS, Parcel Post, or Air Freight, insured and prepaid.

NOTE: DO NOT SEND COLLECT - collect shipments will be refused and returned to sender.

Orange Micro, Inc. disclaims any liability to users of the Orange Micro product for consequential damages of any kind arising from or connected with the use of the Orange Micro product.

This warranty is void in cases of misuse, abuse, abnormal conditions of operations or attempts to alter or modify the function of a part or assembly.

This limited warranty is in lieu of all other warranties expressed or implied, and no representative or other person is authorized to represent or assume for Orange Micro, Inc. any warranty liability beyond that set forth herein.

This warranty gives you specific legal rights, and you may also have additional rights, which vary, from state to state. The warranty expressed herein applies to the Orange Micro product sold and used in the United States of America.

FCC Class B Information

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 7. Reorient or relocate the receiving antenna.
- 8. Increase the separation between the equipment and receiver.
- 9. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- 10. Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio/TV Interference Problems. This booklet is available from the US Government Printing Office, Washington, DC 20402. Stock No. 004-000-00345-4

Index

Adobe Acrobat Reader, 8, 10

Adobe Premiere 5.1 Capturing Video, 14 Extensions and Control Panels, 13 Apple QuickTime, 4 blocky video, 18 BTV, 8 BTV Pro, 4, 8, 13, 14, 15 camera driver, 20 capture video, 17, 18 CardBus PC Card, 4 choppy sound, 17, 21 Customer Service, 23 Customer Service hours of operation, 23 Device Manager, 10, 17, 20, 21 Ethernet, 12, 17 fdisk, 20 FireWire, 5 FireWire cable, 12 FireWire disk, 5, 11, 20 FireWire PC Card, 12 FireWire PCI. 6, 11, 12, 22 FireWire/Ethernet, 12 FireWire/SCSI U2W, 12 How to install an OrangeLink in your Macintosh, 6 Install an OrangeLink in your PC, 9 Installing FireWire Drivers, 7 Installing OrangeLink Drivers in the Mac OS, 6

Installing OrangeLink Drivers in Windows, 9 Mac OS 8.6, 18 Mac OS X, 7 Mac will not boot, 18 Macintosh Troubleshooting, 18 mass storage, 20 OrangeLink Hardware Accessories, 12 FireWire cable, 12 FireWire Hub, 12 FireWire Repeater, 12 Orange Converter, 12 Output to FireWire, 14 Output Video to FireWire, 14 Package Contents, 4 PC Troubleshooting, 20 PowerBook. 5 QuickTime, 4, 8, 13, 19 recommended updates, 20 Software included, 4 Sound, video and game controllers, 20 System Requirements, 4 Ulead VideoStudio, 10, 16 USB 2.0, 12 USB 2.0 Certified cable, 12 USB 2.0 Hi-Speed, 12 VideoStudio, 10, 16 Warranty Information, 23



"22 Years of Innovation and Excellence" 1400 N. Lakeview Ave., Anaheim, CA 92807 (714)779-2772 • www.orangemicro.com